

Tvheadend - Bug #5775

don't pass to the next sat>ip

2019-11-14 13:08 - Ricardo Rocha

Status:	New	Start date:	2019-11-14
Priority:	Normal	Due date:	
Assignee:	Jaroslav Kysela	% Done:	0%
Category:	SAT>IP	Estimated time:	0.00 hour
Target version:		Affected Versions:	
Found in version:	HTS Tvheadend 4.3-1852~gdea96e441		
Description			
i have 3 minisatips each of them with more than 4 tuners and all connected to same network.			
if i unplug connectivity from one of them tvh keep trying another tuner on the same minisatip but never move to another one, is there any trick?			

History

#1 - 2019-11-14 16:37 - Flole Systems

Works fine for me, it falls to the next-lowest priority when no signal is detected.

#2 - 2019-11-14 16:48 - Ricardo Rocha

Maybe that's the problem... It's not a no signal. It's a non controlled shutdown... For example power shut... Maybe some tear down missing or something like that. Or and more probably since I have minisatip 0/1/2 and have the 0 With tuners with higher priority something like 7 8 9 10... When I disconnect and suppose it's working on 10 it tries 9 then 8 then 7 then 10 again.... And never pass to the minisatip 1 or 2 tuners

#3 - 2019-11-15 00:22 - Flole Systems

<https://tvheadend.org/projects/tvheadend/wiki/Debugging>

Provide --trace satip

#4 - 2019-11-15 02:32 - Ricardo Rocha

will try to do it as fast as possible!